



Save These Instructions for Future Reference

ALL CONNECTIONS TO BE CARRIED OUT BY A QUALIFIED ELECTRICIAN
PLEASE READ CAREFULLY BEFORE STARTING INSTALLATION.



⚠ WARNING

Electronic Control Device

ELECTRIC SHOCK HAZARD
This equipment is to be serviced by trained personnel only.

6

6. Switch on power supply.

Miso - Interior & Exterior

Save These Instructions for Future Reference

Electrical products can cause death, injury, or damage to property. Installation of this product must be carried out by a qualified electrician, in compliance with SANS 10142 or corresponding regulations of the country of installation. On completion of installation, the Certificate of Compliance must be updated.

WARNING: TO AVOID FIRE, SHOCK OR DEATH
TURN OFF POWER AT CIRCUIT BREAKER OR FUSE AND TEST THAT THE POWER IS OFF BEFORE WIRING

ALL LUMAIRES SUPPLIED AND TO BE INSTALLED ABOVE AND BELOW 5 METERS ARE IN COMPLIANCE WITH SANS 60598 SECTION 3.5.6 ACCORDING TO THE MANUFACTURER GUARANTEE AND WARRANTY

Regent Lighting reserves the right to change specifications modify designs and discontinue items without incurring obligation and whilst every effort is made to ensure that descriptions, specifications and other information in this catalogue are correct, no warranty is given in respect thereof and the company shall not be liable for any error therein.

www.regentlight.co.za

REGENT LIGHTING A DIVISION
OF WAHL INDUSTRIES.

3 - 13 MAIN REEF SERVICE ROAD, CORNER
SPRINGBOK AND MAIN REEF ROAD, INDUSTRIAL,
JOHANNESBURG, SOUTH AFRICA.
TEL : +27 11 474 0171

November 2017

www.regentlight.co.za



REGENT
LIGHTING
SOLUTIONS

Miso
Interior & Exterior

INSTALLATION INSTRUCTIONS

PLEASE READ CAREFULLY BEFORE STARTING INSTALLATION.
ALL CONNECTIONS TO BE CARRIED OUT BY A QUALIFIED ELECTRICIAN



⚠ WARNING


Electronic Control Device

ELECTRIC SHOCK HAZARD
This equipment is to be serviced by trained personnel only.

DO NOT CONNECT THE FITTING LIVE

1

**THE FINISHED SURFACE LEVEL NEEDS TO BE
BE FLUSH WITH THE OPENING OF THE WALL BOX**




Requirements:

- Be sure the electricity to the system you are working on is isolated.
- If the main supply power (live) is on, it will cause damage to the luminaire.


1. Select the required position for the luminaire.

Ensure the cut out is level and square and fits the metal electrical wall box with an electrical supply.



INSTALLATION TOLERANCE

NB!!! The Light Fitting once installed into the wall box has a movement tolerance of 6mm to secure fitting.



THE FSL (Finished surface level) NEEDS TO BE FLUSH WITH THE OPENING OF THE METAL WALL BOX.

NB: There is an installation tolerance on the fitting.

www.regentlight.co.za




Important Safety Instructions

- This product should be installed by a competent person i.e. Qualified electrician.
- This product requires a constant stable electrical supply 220V - 240V VAC 50Hz - alternating current.
- The product must be regularly maintained, including the replacement of lamps/LED timeously.
- This product could be HAZARDOUS if not used correctly, it could cause electric shock, serious bodily harm or death.
- This product is not a toy, please keep away from children.
- This product may contain small parts that can be swallowed.



- Use only the correct light bulbs/LED as stipulated on the carton for the product.
- Any modifications of this product after supply will result in the guarantee being void.
- Spare parts may become unavailable over time. Items can vary slightly from the picture on the carton
- Coastal humidity can affect the longevity of the light fitting over time.
- Be sure to follow the steps in the order given.
- Read instructions carefully.

2 MOUNTING



2. Feed the electrical cable through the cable entry hole on the wall box by selecting the entry point closest to the main supply.

Insert the wall box into the wall and secure the wall box with wall plugs/screws.


Ensure there is no trapped or pinched insulation.

Ensure the wall box is level vertically and horizontally.

Insert wall plugs into the wall before fastening the wall box to the wall.

Adjust the wall box accordingly before finishing the wall, ensuring the wall box is level and secure.

3 PLASTERING / FINISHING




3. FINISHING THE SURFACE:

Finish the wall by plastering up to the box opening.

Clean the excess plaster around the wall box opening.

4 CONNECTION



4. Strip the main power supply cable (Live, neutral and earth), before connecting.


Separately connect the Live, Neutral and Earth from the mains power supply to the electrical cable tail supplied on the fitting using 3 resin connectors (**Connector: 3M - J000788**) to maintain the IP rating.

(L) Brown/
(N) Blue/
(E) Green/yellow

(L) Brown/
(N) Blue/
(E) Green/yellow

Inset the two corresponding cables Push the button on the connector (indicated in red/orange) to release the gel resin once the electrical cables are secure.

5 INSTALLATION



5. Push the luminaire into the wall box.

Ensure that there are no exposed conductors, loose strands or trapped insulation.